


Installation

Important information regarding installation - READ CAREFULLY


- Keep the sensor and its cable away from electro-magnetic sources such as coils, sockets, spark plugs, etc.
- Do not tighten the sensor too much to avoid damaging it

The thermocouple must be installed on the exhaust pipe, approximately 20 cm from the cylinder collector. If the pipe does not already include it, perform a 5mm hole about 20 cm from the collector, weld the M5 nut included and screw the thermocouple sensor to the nut. **Make sure the thermocouple wire isn't close to electromagnetic sources such as coils, ignitions, etc.**



Specifications

	SSEK100
Range	0 – 800 °C
Cable lenght	30 cm
Weight	19 gr




Installazione

Note importanti di installazione – LEGGERE ATTENTAMENTE

- Evitare che il sensore ed il rispettivo cavo siano in prossimità di fonti elettromagnetiche come bobine, accensioni, candele, etc
- Non stringere il sensore con troppa forza per evitare di danneggiarlo

La termocoppia dovrà essere installata sullo scarico a circa 20cm dal collettore del cilindro. Nel caso in cui il tubo non ne sia già provvisto praticare un foro da 5mm a circa 20cm dal collettore, saldare il dado M5 in dotazione e successivamente avvitare la sonda termocoppia al dado. **Fare attenzione a non far passare il cavo della termocoppia vicino a fonti elettromagnetiche come bobine, accensioni, etc.**



Specifiche

	SSEK100
Range di misura	0 – 800 °C
Lunghezza cavo	30 cm
Peso sonda	19 gr

